

# T-POINT LIFT SPECIFICATION AND STANDARD FEATURES:

Slides into any standard 2-inch receiver with solid 2 inch receiver mount

Designed for category 1 tractor implements. Light weight Cat 0 implements can also be used. Fully Adjustable

Can be installed on Pickup trucks, SUVs, larger utility vehicles and ATVs

Integrated 12V Hydraulic system that uses only 3 quarts of fluid with fully wired remote activated control.

**Integrated Safety chains** 

Fully painted heavy wall steel

Has the capability to lift over 2000 LBS\* \*When installed on Full Size Pickup, Full size Van or Full size SUV with frame mounted receiver hitch\* Order on line at www.t-pointlift.com

# TURN YOUR TRUCK, JEEP, SUV OR LARGE UTILITY VEHICLE INTO A REAL WORKHORSE!



We provide people with durable and functional equipment made in the USA and built to last.





## T-POINT LIFT...

**US PATENT PENDING** 

THREE POINT HITCH FOR YOUR VEHICLE, UTV OR ATV



PUT YOUR
IMAGINATION TO
WORK ON WAYS YOU
CAN PUT THE T-POINT
LIFT TO WORK.

WITH PRICING A FRACTION OF THE COST OF A RELIABLE TRACTOR.

www.t-pointlift.com

Ever wonder what the term "necessity is the mother of invention" really means. It means, being able to create something that is highly useful and possibly take the place of some other item, which you may or may not have.



The T-Point lift

does just that. It adds a three-point hitch that turns your vehicle into a tractor like device that is capable of breaking ground, leveling dirt and gravel, digging shallow trenches, plowing snow, and any other task that would require a small to midsized tractor. The 3-point design can utilize most category 1 implements not requiring a PTO.

From prepping your deer and turkey plot to trail maintenance, snow plowing, fixing roads and driveways, the **T-Point Lift** can handle it all. There are many other uses to put the T-point to work, but you can decide which is best suited for your applications

### T-POINT SUGGESTED USES:

Put in your wild game feed plots or any other small planting or cultivating task without a tractor. Put a small disk behind your vehicle and you can prepare for planting



- Add a sub soiler and you can cut roots while digging small trenches for wire and or plumbing.
- Put a T-Point Lift behind a
   Jeep or large UTV and you have a maintenance package for small trails.
- Maintain rural roads and driveways without the use of heavy equipment, which saves fuel and money.

Civilian and Government discounts available

www.t-pointlift.com

### **T-Point Lift Installation**

It is very simple to install and assemble the T-Point Lift.

- 1. Insert the frame assembly into your 2-inch receiver, installing the retaining pin and safety chains.
- 2. Next, you place the upper lift arm onto the T-Point Frame with quick attach pin. Then Install the lower lift arms at this time with two small retaining pins.
- 3. Mount the Hydraulic power pack to the frame assembly. Then install the hydraulic cylinder with two quick attach pins. After Hydraulic cylinder is installed, the two adjustable lift links can be installed between upper lift arm and lower lift arms.
- 4. Connect electrical connector to positive terminal on battery and place remote control within easy reach while operating vehicle.
- 5. Hook up your CAT 1 implements and put them to use behind your vehicle or UTV. When it is time to remove the device, you have two options. Leave the implement attached and remove the T-Point from the receiver fully assembled or disconnect the 3-Point implement and then remove the T-Point. It is that simple.